

- Tools Needed
 - 10 mm socket
 - 5/8 inch spark plug socket
 - Socket wrench with extension
- Parts
 - Spark plugs (8) (Iridium)
 - Denso SK20R11 (10 12 \$ a piece) or
 - NGK − IFR6T11 (6 − 8 \$ a piece)



Step 1 Remove plug covers





- Remove Plugs
 - Use a spark plug socket to make this easier





- Install new plugs
 - Be careful not to over-tighten the plug
 - Finger tight plus about a 1/8 of a turn





- Re-Install plug covers
- Clean-up the mess you made
- Head to the lake!



- Look familiar! (Oil in the plug cylinder)
 - You probably have a gasket that is leaking in to the spark plug cylinder. Do a search on the forum for more information on this. This is a fairly common occurrence.

