

Technical Service Bulletin 30
Tower Transportation Support
March 16, 2000

Parts Needed

Transportation Support, Black – MPE0011658
OR
Transportation Support, White – MPE0011659

Procedure

Step 1 – Mounting Tower On Support

Lower the wakeboard tower onto the Tower Support, placing the support in the middle of the tower. The Tower Support should be positioned so the shorter side of the receiver cup faces towards the bow. Do not support at an angle it must stand straight up and down

Step 2 – Strapping Down The Tower

Adjust the black tie down strap to hold the tower Tower Support. The tie down strap was shipped with the boat and was used to hold the tower against the cardboard shipping support. The end of the tie down strap clips onto the loop located on top of the tower, just forward of the tower pylon. The other end of the strap clips to the loop located near the floor at the very front of the open bow passenger area.

Note: Tower Transportation Support is use while the boat is being trailered or not use Tower Support while the boat is being used on the water.

